

## Wireless, Pedals, 3 Channel Amp Switching

This setup has a wireless unit and noise gate which are routed directly to the rear of the GCX's first loop. It also has 3 pedals running in front of the amp while using the rest of the GCX to switch the amp's channels and FX loop.

